

Push Button Switch



CXB2-EW8465



CXB2-ED21



CXB2-EG33



CXB2-ES542



CXB2-ES142



CXB2-BE101



CXB2-BE102












CXB2-BZ102






CXB2-BZ101

Parameters of CXB2 Push Button Switch:

Control Signaling Units 22mm				
Description	Contact type	Scheme	Operator head	Reference

2 Positions stay out	N/O		Standard handle	CXB2-D21
			Long handle	CXB2-EJ21
	N/O+N/C		Standard handle	CXB2-ED25
			Long handle	CXB2-EJ25
2 Positions 1 spring return from right to left	N/O		Standard handle	CXB2-ED41
			Long handle	CXB2-EJ41
	N/O+N/C		Standard handle	CXB2-ED45
			Long handle	CXB2-EJ45
3 Positions stay out	N/O+N/C		Standard handle	CXB2-ED33
			Long handle	CXB2-EJ33
3 Positions 2 spring return from right to left	N/O+N/C		Standard handle	CXB2-ED3
			Long handle	CXB2-EJ53
2 Positions stay out	N/O			CXB2-EG21
				CXB2-EG45
	N/O+N/C			CXB2-EG25
				CXB2-EG45
3 Positions stay out	N/O+N/C			CXB2-EG33
				CXB2-EG53
				CXB2-EG03

Return reset Φ 40mm	N/C			
n°455 Φ 40mm	N/C			CXB2-ES542
				CXB2-ES142
				CXB2-EW8465
N/O				CXB2-BE101
N/O				CXB2-BE102
N/O				CXB2-BZ101
N/O				CXB2-BZ102
N/O +N/O				CXB2-BZ103
N/C+N/C				CXB2-BZ104
N/ON/C				CXB2-BZ105